



## U6 V3 Motorola Data cable Installation Guide

Compatible with: Motorola c330 , c331, c332 c333 c350 c370 c650 mpx200 v180 v186 v188 v220 Razr v3 Razor v3 v3c v3i v3i v323 v3x v325 v360 v360v U6 PEBL SLVR L6 L7 L8...

- Insert the Driver CD (NOT the blank fun CD) into CD ROM, it will start automatically after a couple of seconds
- Follow the prompts and you will get to 'Finish', anything not sure, there is a PDF User Guide in the CD.

### Trouble shooting:

1. If after installing software the cable and the phone does not click, please in Control Panel/System/Hardware device, right click 'modem'-->properties, and find the COM value of the modem (e.g. 4);
2. Launch the Moto software, in 'settings', there is a interface for you to set the same COM value (e.g. 4) you just found, and it should work from then on...
3. The other possible reason for not connecting is that your phone's settings stopping the phone from connecting with data cable, e.g., you may have to go into the connectivity menu in the phone and change it from the memory card to the data cable.
4. Please note, this cable does not have IC so when plugged in USB by itself, there will be NO 'Found New Hardware' Window turning up, unless you plug in with your phone which is only recommended AFTER driver and software installed OK.

\* Please note: The instructions here may only be used for information only, the actual installation might not happen exactly as instructed, due to the product development, and various settings of PCs, and the software versions etc.

If you have further questions please feel free to contact us. cheers,  
Thank you and enjoy your purchase!

### **\*Windows Vista users with Moto Phone: V3, V3c, V3i, V3t, V3x, and Motorola V3m**

Motorola has recently published on April 12, 2007 their own updated version of the [USB drivers](#) for the 64-bit editions of Windows Vista and Windows XP on their MOTODEV [website](#).

1. Visit the Motorola MOTODEV website <http://developer.motorola.com/> (registration required, but it is an immediate confirmation and access to the page).
2. After logged in, go [here](#) ([http://developer.motorola.com/docstools/USB\\_Drivers/Handset\\_USB\\_Driver\\_64/?login=1](http://developer.motorola.com/docstools/USB_Drivers/Handset_USB_Driver_64/?login=1)) for Motorola Handset USB Driver v2.9.0 (or newer) for Windows ([64-bit](#)) OS [here](#) and download the drivers (only approx 2.5Mb).
3. Disconnect your Motorola V3 RAZR phone from the USB cable.
4. Double-click on the downloaded file to start the installation of the USB driver software.
5. Click 'Next' on the screen for "Welcome to the Motorola Driver Installation Setup Wizard".
6. Select the 'I Agree' under the license agreement and click 'Next'. The Motorola Driver Installation is being installed dialog installs the driver.
7. The installation completes and click on 'Close' to exist the installation.
8. Plug in your Motorola V3 RAZR phone and it should work with other USB services.

This guide is compatible with the Motorola V3, V3c, V3i, V3t, V3x, and Motorola V3m. In addition, the drivers should support most Motorola OS, Motorola Linux OS, Motorola iDEN, Motorola Symbian/UIQ, Motorola Windows Mobile® and Motorola i-Mode handsets.

Copyright [www.ancglobal.net](http://www.ancglobal.net) © 2007, all rights reserved.