



IVT Bluesoleil 2.6 or newer Installation Guides (Text)

1. Make sure the Bluetooth dongle is off computer during software installation.
2. Put driver CD into CD-ROM drive, installation problem should launch automatically. If program doesn't run automatically, please run "setup.exe" in CD drive root manually.
3. Use default English as setup language, click "OK".
4. Click "Next" on below screen.
5. Chose "I accept the terms in the license agreement", click "Next".
6. Click "Next" on the following screen.
7. Click "Next" on the following screen.
8. Click "Install" on the following screen.
9. The program is installing, it will take 1 or 2 minutes.
10. Click "Finish" to close the following window. Then restart the computer.
11. The following screen should display after computer restart.
12. Plug Bluetooth dongle into an USB port. The computer should detect new hardware automatically. Some message should pop up at the right bottom corner.
13. Wait for a short while, the following window should display on the screen. Type in the preferred name you want, and then click "OK". The device name is Bluetooth ID for this computer when using Bluetooth.
14. Click "Start" -> "Settings" -> "Control panel" -> "System"-> "Hardware" -> "device manager", then the following window should display on the screen. Make sure an icon called "Bluetooth" should display in the window. The icon shouldn't have yellow or red mark on it. The below picture shows a properly installed Bluetooth. If everything is ok, close the window. The Bluetooth dongle is ok now.
15. So far, the Bluetooth dongle hardware and software installation is complete. How to establish a connection between a Bluetooth mobile phone and Bluetooth dongle is shown below.
16. Enable Bluetooth function on your mobile phone, and then click the sun in the center of below screen to searching the available Bluetooth device. If the mobile phone is found, a mobile icon should display on the screen like below.
17. A few icons on the screen turn to yellow with square yellow border. They indicate available functions
18. Click icon to launch file transmission. The password window display on the screen like below. You should type in a password into both your mobile phone and text box in the screen. The passwords provided on computer and mobile phone should be same, and they are used to identify each other. Please note this step should be done quickly, slow operation may cause timeout.
19. After Bluetooth connection is established, the following window display on the screen. It can be used to transfer the photo and ring tones bi-directionally (upload and download).